



5. THE CONCRETE MUST SET FOR 48 HOURS BEFORE PIPE INSIDE OF MANHOLE IS TRIMMED.

7. WATER STOPS MAY BE ELIMINATED IF BARREL OF MANHOLE IS POURED WITHIN 4 HOURS AFTER BASE IS POURED AND PROVIDED BASE IS CLEANED OF ALL MUD, SILT, AND DEBRIS.

6. (ALTERNATE 3) INVERT MUST BE FORMED AT TIME OF BOTTOM POUR.

8. THE MINIMUM INVERT DEPTH SHALL BE 3/4 TIMES THE PIPE DIAMETER.

SANITARY SEWER MANHOLE WITH FLAT SLAB TOP

CITY OF TULSA, OKLAHOMA ENGINEERING SERVICES DEPARTMENT

DRAWN BY: R.M.O. CHECKED BY: HAS DATE: FEB 2023

NOT TO SCALE

STANDARD NO. 357